



## MORRIS MINOR OIL FILTER ADAPTOR FITTING INSTRUCTIONS

**Please** read all the instructions before starting work on your car.

The kit contains:

- Rubber seal
- Aluminium adaptor plate
- Bolt
- Oil filter

*(This diagram is for illustration purposes only)*



Remove the old oil filter. Clean the face thoroughly.

Place the small rubber seal in the centre of the adaptor plate and offer up to boss on block. Insert the locating bolt supplied with this kit through the plate and screw it up finger tight, making sure that it seats properly against the seal. Tighten up carefully with a  $\frac{3}{4}$ " spanner but be sure not to over-tighten.

You are now ready to fit a spin-on filter to your Morris. Use a Crosland 659 or similar high quality filter with a 3/4UNF thread. Remember to fill the filter with oil before fitting and change it at the recommended intervals.

Never tighten a spin-on filter with a filter removal tool.

Also available for Morris Minors: braided stainless steel flexible brake hoses, clutch hoses, fuel and oil lines, pressure gauge lines, fuel filters etc.