



## VAUXHALL VIVA/CHEVETTE OIL FILTER ADAPTOR FITTING INSTRUCTIONS

PLEASE read instructions all the way through BEFORE fitting the oil filter adaptor.

The kit contains:

- Aluminium adaptor plate
- Small o-ring
- Large o-ring
- Canister bolt
- Oil filter



*(The diagram is for illustration purposes only)*

Remove the old canister and filter. Remove the rubber seal which sits in the groove and seals the original canister. Place the small o-ring supplied with this kit in the shallow groove in the centre of the alloy adaptor plate. Place the larger o-ring in the groove in the engine block. Carefully offer up the alloy plate ensuring that the small o-ring does not move out of place (it can be held in place with a few dabs of grease). With the adaptor plate in position insert the locating canister bolt and screw it in finger tight. Tighten fully using a 1"AF socket (do not over tighten).

You are now ready to fit a spin-on filter. We recommend a Crosland 357, Mann W916/1, Coopers Z27A or similar high quality filter. The 357 has an anti-drain valve which will help to improve start-up oil pressure. Always grease the filter sealing ring before installation. Observe the manufacturer's change intervals.

Fitting a Flexolite oil filter adaptor makes it easy to fit an oil cooler to your car. Contact Flexolite for further details.