



RILEY RME

**NOTES ON FITTING YOUR FLEXOLITE
OIL FILTER ADAPTOR KIT**

Remove existing filter complete with head from side of block.

Using head as template mark out and drill 3rd hole in filter head supplied.

Then bolt replacement filter head to block screwing original pipework into appropriate bosses.

Fit spin on filter as supplied.